

**VULCAN**


*CATALOG OF  
REPLACEMENT PARTS*

*TILTING SKILLET*

MODEL

VECTS16    ML-114825





TILTING SKILLET ASSEMBLY

### TILTING SKILLET ASSEMBLY

ILLUS. PL-52816	PART NO.	NAME OF PART	AMT.
1	00-851370	Cover Assy. ....	1
2	00-836964	Knob .....	1
3	00-851372	Handle .....	1
4	00-851373	Nut - Acorn .....	1
5	00-851375	Element (208V, 2.5 KW) .....	3
6	00-851376	Element (240V, 2.5 KW) .....	3
7	00-851524	Element (277V, 2.5 KW) .....	3
8	00-851377	Clamp - Capillary .....	1
9	00-851378	Clamp - Element .....	1
10	00-851379	Insulation - Pan .....	1
11	00-851380	Cover - Bottom .....	1
12	00-851371	Pan Assembly .....	1
13	00-851374	Bearing .....	2
14	00-851382	Cover - Console (R.H.) .....	1
15	00-836832	Thermostat - Hi - Limit .....	1
16	00-851384	Plate - Compartment Mtg. ....	1
17	00-844367-00008	Lug - Ground .....	1
18	00-844367-00051	Block - Terminal (208V. Thru 480V.) .....	3
19	00-844367-00052	Section - End .....	1
20	00-881975	Contactora (30 Amp) (208/240/480V.) .....	2
21	00-851383	Decal - Operation .....	1
22	00-840467	Thermostat - Operating .....	1
23	00-844367-00005	Bezel .....	1
24	00-844063	Dial .....	1
25	00-881972	Pilot Light (Amber) .....	1
26	00-851322	Boot - Rubber .....	1
27	00-881970	Switch - Power .....	1
28	00-851381	Cover - Console (L.H.) .....	1
	00-851541	Stand Assy. (Complete W/Sliding Drain Pan) .....	1
	00-851566	Pan - Sliding Drain .....	1
	00-850604	Foot - Adjustable .....	4
	00-851542	Strainer .....	1
	00-851385	Bracket - Thermostat .....	1
	00-843994	Transformer (480 Primary)(120V Secondary)(50/60/100VA) .....	1
	00-844546	Fuse (1 Amp, 600V, 380/416/480V) .....	2
	00-850489	Block - Fuse (380/415/480V) .....	2

