

# INSTALLATION INSTRUCTIONS


## 00-857112-00001 TEMPERATURE CONTROLLER

### SERVICE INFORMATION

**NOTE:** These instructions are only intended for use by properly trained and qualified service technicians. If you do not have technical training for this product, you should read the following procedure, in its entirety, to determine if you have the necessary tools, instruments and skills required to perform the procedure. Procedures for which you do not have the necessary tools, instruments and skills should be performed by a trained Hobart Service technician. The reproduction, transfer, sale or other use of this manual, without the express written consent of Hobart Service, is prohibited.

Used on VG30, VG40 VE30, and VE40 Braising Pans and K Series Kettles. Wiring has changed due to manufacturing changes to controller.

### TEMPERATURE CONTROLLER WIRING DIAGRAM




AI3670

Fig. 1

### NOTICE

Current controller replaces previous controller; each is wired differently.



Manufacturers Previous Controller



Current Controller