

Why	Long reliable service life	
Time required	5 minutes to prepare	15 minutes to complete
Time of day	At closing	For 24-hour restaurants: Slowest time of day

Hazard icons	 Chemicals	 Compressed Gas/Air/Liquid	 Electricity	 Hot Liquids/Steam	 Hot Oil
	 Hot Surfaces	 Manual Handling	 Moving Parts	 Moving Vehicles	
	 Sharp Objects/Surfaces	 Slippery Floors	 Syringes & Body Fluids		

Tools and supplies

Rubber mallet or a hammer with a block of wood.

Procedure

- Step
Open cabinet door (s) to inspect gasket.



- Step
Pull gasket with hand and visually inspect gasket (s) for tear, dirt, mold or worn gasket. Replace as needed. Model and serial number is required when placing a parts order Traulsen 800-825-8220.



- Step
Gasket can be removed by firmly grasping one corner and pulling out. Before attempting to install a new gasket, both the unit and the gasket must be at room temperature. When replacing the gasket insert the four corners by using a rubber mallet (or hammer with a block of wood). After the corners are properly inserted, work your way towards the center from both ends by gently hitting with a mallet until the gasket is completely seated and in place.

