
## ASSEMBLY INSTRUCTIONS MIXER TABLE ML-134299

## FOR HL120 or HL200 MIXERS

This instruction describes the assembly and lists the parts needed for the mixer table.



Description	Qty.	Description	Qty.	Description	Qty.
Тор	1	Washer	22	Shelf	1
Support Channel	3	Nut	22	Caster	4
Leg, Rear	2	Grommet	12	Post	4
Leg, Front	2	Rod (short)	2	Screw	8
Screw	22	Rod (long)	4	Lockwasher	8

- 1. Remove all protective film from top and shelf.
- 2. Lay top on flat surface with underside up. Install the three support channels; match up holes in support channels to holes in underside of top, with six \(^1/\_4\)-20 x \(^1/\_2\)" screws, washers and nuts.



3. Loosely attach three legs, two rear and one front, to the underside of top with six  $^{1}/_{4}$ -20 x  $^{1}/_{2}$ " screws, washers and nuts.



701 S. RIDGE AVENUE TROY, OHIO 45374-0001 937 332-3000 www.hobartcorp.com

## MIXER TABLE ML-134299 (cont)

- 4. Install casters into bottom of legs.
- 5. Install 14 grommets into holes in legs.
- 6. Install rods (longer on sides, shorter on rear) into loosely installed legs. Lubricate rod ends with dish soap to make installation easier. Tighten all screws.
- 7. Install shelf onto three leg brackets with (6)  $^{1}/_{4}$  -20 x  $^{1}/_{2}$ " screws, washers and nuts.
- 8. Install rods into remaining leg.
- 9. Attach leg onto shelf and underside of top using  $(4)^{1}/_{4}$ -20 x  $^{1}/_{2}$ " screws, washers and nuts.
- 10. Place table on its side and install four posts to top at rear of top with (4)<sup>3</sup>/<sub>8</sub>-16 x<sup>3</sup>/<sub>4</sub>" screws and lockwashers.



- 11. Turn table upright.
- 12. Use 3/8 16 X 3/4 screws and 3/8 lockwashers to bolt mixer to the table.

**NOTICE** All components must be assembled prior to use.



F34935B (May 2008) PRINTED IN U.S.A.